

# Ringseal Pinza K4

## Dilating pliers for hydro-expansive seals



Special dilating pliers with three noses, to facilitate the installation of the rectangular seals Ringseal L19 in a central position with respect to the metal blade caisson spacers for wood formwork.

**CUSTOMS CODE:** 8203 2000

**COMPONENTS:** Single-component

**APPEARANCE:** Pliers

**AVAILABLE COLORS:** Black

**PACKAGING AND DIMENSIONS:** Bulk material 1 unit

## FIELDS OF APPLICATION

Expansion of elastic seals. Specific for the installation of the hydro-expansive rings Ringseal L19 on blade caisson spacers.

## MODE OF USE

Fully insert the nose of the pliers in the closed position in the slit of the rectangular gasket Ringseal L19. Press the handles of the pliers in order to dilate the seal. Install the dilated gasket at the centerline of the metal caisson blade. Release the pliers and pull them out of the seal.

## KEY FEATURES



Unlimited shelf-life

## CONSUMPTION

Product to buy as needed.

## STORAGE AND CONSERVATION

Store the product in its original packing, in a fresh and dry environment, avoiding frost and direct sunlight.

## PHOTO GALLERY



## ADDITIONAL CONTENT



## WARNINGS AND PRECAUTIONS

The pliers are provided with a maximum adjustable opening fastener, in order to limit the maximum expansion of the seal, so as not to damage it. Reduce the maximum opening, by adjusting the above-mentioned fastener, in case of any damage to the seals. The general information, along with any instructions and recommendations for use of this product, including in this data sheet and eventually provided verbally or in writing, correspond to the present state of our scientific and practical knowledge.

Any technical and performance data reported is the result of laboratory tests conducted in a controlled environment and thus may be subject to modification in relation to the actual conditions of implementation.

Azichem Srl does not assume any liability arising from inadequate characteristics related to improper use of the product or connected to defects arising from factors or elements unrelated to the quality of the product, including improper storage.

Those wishing to utilise the product are required to determine prior to use whether or not the same is suitable for the intended use, assuming all consequent responsibility.

The technical and characteristic details contained in this data sheet shall be updated periodically. For consultation in real time, please visit the website: [www.azichem.com](http://www.azichem.com). The date of revision is indicated in the space to the side. The current edition cancels out and replaces any previous version.

Please note that the user is required to read the latest Safety Data Sheet for this product, containing chemical-physical and toxicological data, risk phrases and other information regarding the safe transport, use and disposal of the product and its packaging. For consultation, please visit: [www.azichem.com](http://www.azichem.com).

It is forbidden to dispose of the product and/or packaging in the environment.

